tC

2009

QUICK REFERENCE GUIDE

GET INFORMED.
ROLL.

what moves you

2009
Scion tC

This *Quick Reference Guide* is a summary of basic vehicle operations. It contains brief descriptions of fundamental operations so you can locate and use the vehicle's main equipment quickly and easily.

The *Quick Reference Guide* is not intended as a substitute for the *Owner's Manual* located in the vehicle's glove box. We strongly encourage you to review the *Owner's Manual* and supplementary manuals so you will have a better understanding of the vehicle's capabilities and limitations.

Your dealership and the entire staff of Scion, a marque of Toyota Motor Sales, U.S.A., Inc., wish you many years of satisfied driving in your new SCION tC.

! A word about safe vehicle operations

This *Quick Reference Guide* is not a full description of SCION tC operations. Every SCION tC owner should review the *Owner's Manual* that accompanies this vehicle.

Pay special attention to the boxed information highlighted in yellow throughout the *Owner's Manual*. Each box contains safe operating instructions to help you avoid injury or equipment malfunction.

All information in this *Quick Reference Guide* is current at the time of printing. Toyota reserves the right to make changes at any time without notice.

INDEX

OVERVIEW	Engine maintenance	7
	Fuel tank door opener and cap	6
	Hood release	7
	Indicator symbols	5
	Instrument cluster	4
	Instrument panel	2-3
	Keyless entry	6
FEATURES/OPERATIONS	Air Conditioning/Heating	14
	Automatic Transmission	8
	AUX audio jack	14
	Clock	14
	Cruise control	10
	Cup holders	8
	iPod jack	15
	Light control-Instrument panel	13
	Lights & turn signals	11
	Panorama moonroof	12
	Parking brake	8
	Power outlet	13
	Seat adjustments-Front	9
	Seat adjustments-Rear	9
	Seats-Head restraints	9
	Steering wheel switches	15
	Tilt steering wheel	10
	Windows	13
	Windshield wipers & washers	12
SAFETY AND EMERGENCY FEATURES	Door locks	16
	Seat belts	16
	Spare tire & tools	17
	Tire Pressure Monitoring (warning) System	16

OVERVIEW

Instrument panel



1. Headlight and turn signal controls
2. Steering wheel audio controls*
3. Wiper and washer controls
4. Emergency flasher switch
5. Clock, Air Conditioning and outside temperature display
6. Air Conditioning controls
7. Rear window defogger switch
8. Outside temperature display switch
9. Clock adjustment buttons
10. Front passenger seat belt reminder light
11. Front passenger occupant classification indicator
12. Cigarette lighter
13. Engine immobilizer system indicator
14. Engine switch
15. Cruise control
16. Tilt steering lock release
17. Power outside rearview mirror controls

* For details, refer to the *"SCION Audio System Owner's Manual" or "SCION Navigation System Owner's Manual."*

Instrument cluster



1. Engine coolant temperature
2. Fuel gauge
3. Speedometer
4. Tachometer
5. Service indicator and reminder
6. Automatic Transmission shift position indicator
7. Trip meter reset knob
8. Odometer and two trip meters
9. Low fuel level warning
10. Instrument panel light control knob

Indicator symbols

BRAKE	Brake system warning[1]
	Driver seat belt reminder[1] (alarm will sound if speed is over 9 mph)
PASSENGER	Front passenger seat belt reminder[1] (alarm will sound if speed is over 9 mph)
	Charging system warning[1]
CHECK	Malfunction/Check Engine indicator[1]
	Low engine oil pressure warning[1]
	Open door warning[1]
	Airbag SRS warning[1]
	Low Tire Pressure Warning[1]
MAINT REQD	Engine oil replacement reminder[1]
	Turn signal indicators
	Headlight high beam indicator
PRND 32L	Automatic Transmission indicator
CRUISE	Cruise control indicator[2]
ABS	Anti-lock Brake System warning[1]

[1] *For details, refer to "Service reminder indicators and warning buzzers," Section 1-6, 2009 Owner's Manual.*

[2] *If this light flashes, refer to "Cruise control," Section 1-7, 2009 Owner's Manual.*

Fuel tank door opener and cap



NOTE: Tighten cap until one click is heard. If the cap is not tightened enough, Check Engine " CHECK " indicator may illuminate.

Keyless entry

Locking operation



Unlocking operation



NOTE: If a door is not opened within 30 seconds of unlocking, all doors will relock for safety.

Panic button

Hood release



Engine maintenance



1. Power steering fluid reservoir
2. Engine oil filler cap
3. Engine oil level dipstick
4. Windshield washer fluid tank
5. Engine coolant reservoir

Note: Regularly scheduled maintenance, including oil changes, will help extend the life of your vehicle and maintain performance. Please refer to the "Owner's Warranty Information Booklet," "Scheduled Maintenance Guide" or "Owner's Manual Supplement."

Automatic Transmission (if equipped)



* The engine switch must be “ON” and the brake pedal depressed to shift from Park.

Downshifting increases power going uphill, or provides engine braking downhill. For best fuel economy during normal driving conditions, always drive with the shift lever in the “D” position.

Parking brake



Cup holders





Seat adjustments-Front

1. Position
2. Cushion angle (if equipped)
3. Height crank (driver side only)
4. Seatback angle
5. Seatback lock release (if equipped)

Seat adjustments-Rear



Seats-Head restraints



Tilt steering wheel



Hold wheel, push lever down, set angle, and return lever.
Note: Do not attempt to adjust while the vehicle is in motion.

Cruise control

Turning system ON/OFF



Functions



[1] The set speed may also be cancelled by depressing the brake pedal.
[2] The set speed may be resumed once vehicle speed reaches 25 mph.

Lights & turn signals

Headlights



Automatic light cutoff system Automatically turns lights off when driver's door is opened with the engine off.

Turn signals



Windshield wipers & washers



*** Intermittent windshield wiper interval adjustment** Rotate up to increase interval, down to decrease interval.

Panorama moonroof



NOTE: If battery is disconnected, the moonroof needs to be reinitialized. Refer to the *Owner's Manual* for more details.

Windows

Driver door window controls



Automatic operation (all windows) Push the switch completely down or pull it completely up and release to fully open or close. To stop window midway, lightly push the switch in the opposite direction.

Window lock switch Deactivates all passenger windows. Driver's window remains operable.

NOTE: If battery is disconnected, the windows need to be reinitialized. Refer to the *Owner's Manual* for more details.

Light control-Instrument panel



Power outlet (if equipped)



Designed for car accessories. Key must be in the "ACC" or "ON" position to use.

Air Conditioning/Heating



1. Fan speed
2. Air Conditioning/Heating system “OFF”
3. Air Conditioning ON/OFF
4. Fresh or recirculated cabin air
5. Airflow vent
   In “ ” mode, use fresh air (“ ” indicator OFF) to reduce window fogging.
6. Windshield airflow
7. Rear window defogger
8. Temperature

AUX audio jack

By inserting a mini plug into the AUX jack, you can listen to music from a portable audio device through the vehicle’s speaker system. If you do not have a SCION genuine audio system, you will not be able to use the AUX jack.

Refer to the *SCION Audio System Owner’s Manual* or the *SCION Navigation System Owner’s Manual* for more details.

Clock



Steering wheel switches



1. “ ∨ ∧ ”
   -In radio mode Push to select a preset station; push and hold to seek the next strong station.
   -In CD mode Push to skip up or down to a next/previous track.
2. **“MODE”**
   Push to turn audio ON and select an audio mode. Push and hold to turn audio system OFF.

Refer to the *SCION Audio System Owner’s Manual* or the *SCION Navigation System Owner’s Manual* for more details.

iPod jack

By inserting the standard iPod connector cable into the iPod jack, you can charge the iPod battery, control the iPod functions using the car audio unit and listen to music from your iPod through the vehicle’s speaker system.

If you do not have a SCION genuine audio system, you will not be able to use the iPod jack.

Refer to the *SCION Audio System Owner’s Manual* or the *SCION Navigation System Owner’s Manual* for more details.

SAFETY AND EMERGENCY FEATURES

Door locks



Seat belts





If belt is fully extended, then retracted even slightly, it cannot be re-extended beyond that point, unless fully retracted again. This feature is used to help hold child restraint systems securely.

To find more information about seat belts, and how to install a child restraint system, refer to the *Owner's Manual*.

Tire Pressure Monitoring (warning) System

If tire pressure indicator light is on, check/adjust each tire.



After adjusting tire pressures, or after tires have been rotated or replaced, turn the ignition switch to "ON" and press and hold the "SET" button until indicator blinks three times. Then allow the vehicle to sit for a few minutes to allow initialization to complete.

Refer to the load label on the door jamb or the *Owner's Manual* for tire inflation specifications.

If the tire pressure indicator flashes for more than 60 seconds and then remains on, take the vehicle to your local Toyota dealer.

Spare tire & tools

Tool location



Removing the spare tire



(1) Remove the spare tire cover.
(2) Loosen and remove the bolt.

Refer to the *Owner's Manual* for jack positioning and tire changing procedures.

EMAIL
www.scion.com
› Contact

-

CHAT
www.scion.com
› Have a Question?
› Contact

-

PHONE
1.866.70.SCION

-

MAIL
SCION
19001 S. Western Ave.
D102, P.O. Box 2742
Torrance, CA 90509-2742
USA

-

WEB
www.scion.com

-

©2009 Scion, a marque of
Toyota Motor Sales, U.S.A., Inc.

00505-QRG09-TC